

Cabin base, preferred base to be concrete plugs set in ground with 100 mm x 100mm stainless steel box sections set in & wooden bearers bolted across to form a sound base for Cabin to be supported on & anchored to.

Amount of supports to be mutually agreed.

The ground underneath the cabin to have weed control membrane & topped with gravel to assist drainage & keep area clean & tidy.

