17	East elevation	Blown brick face	Remove damaged bricks and replace with undamaged items of similar type/age and correct strength mortar	
18	East elevation	Lack of bearing to opening support	Remove support and replace using correct bearing.	